














SMO4

STEAM ONLY 4.5 BAR WITH STEAM MOPPING KIT


Quick Start Guide

Get setup and ready to clean

WHAT'S INCLUDED


 SO4	 Mains Power Cable 11RM00061 (UK) 11RM00062 (EU)	 User Manual	 Quick Start Guide	 4 Metre Hose 19RM00805
 2 x Extension Tubes 19RM00810	 Brush Elbow 19RM00825	 200mm Hand Tool 18RM00001	 400mm Floor Tool 18RM00002	 200mm Hand Tool Mop Pad 18RM00005
 400mm Floor Tool Mop Pad 18RM00006	 Holdall 18RM00004	 Service Kit	 Glasses	 Gloves

WHAT YOU NEED

- Wear safety shoes gloves, goggles and any other PPE as specified by local regulations
-  Please read and comply with the safety instructions found in the user manual prior to using the machine. Retain this document for future reference. These instructions are also available on our website: www.matrixcleaningsystems.co.uk
- Areas to clean

Lets get started

GET TO KNOW YOUR MACHINE



PREPARE YOUR MACHINE




1. Using clean cold water fill the cold water tank and replace the cap.



2. Lift the flap on the steam hose socket and connect the hose ensuring the pin locks into position.



3. Push your machine to a suitable area and lock the brake lever to avoid the machine moving during use.




4. Plug your machine into a suitable power supply.


Switching on the machine



5. Turn ON the machine with the on/off switch.



6. The heater on LED will illuminate.



7. In Approx. 5 minutes the steam ready LED will illuminate. The machine is now ready to be used.




8. On the steam hose, the steam will disperse when pressed to the on (I) position.


During use



9. The steam output can be adjusted by turning the steam control.



10. Affix your desired accessory for your cleaning task and ensure it is locked into position.



11. Refill Cold water when the refill cold water light illuminates and a intermittent beeping noise can also be heard.